



Desktop Cylindrical Cell Machine Electrode Slitting Machine Max Speed 4m/min

Our Product Introduction

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-FT300
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Name: Desktop Cylindrical Cell Electrode Slitting Machine
- Slitting Width: Standard Is Combined Die For 56mm & 58mm
- Slitting Thickness: 80~300μm Battery Electrode
- Slitting Speed: Max 4m/min, Adjustable
- Working Voltage: AC110V/220V Optional
- Power: 200W
- Highlight: **Desktop Cylindrical Cell Machine,
Cylindrical Cell Machine 4m/min,
Cylindrical Cell Electrode Slitting Machine**

Desktop Semi-auto Cylindrical Cell Electrode Slitting Machine



Model:MR-FT300

Product Introduction

MR-FT300 is slitting machine (roll slitting) for preparing electrode of cylinder and pouch cell batteries in R&D laboratories. Mainly used for the rolling and slitting of positive and negative electrodes after coating of lithium ion batteries. It is slit by a gapless knife, and the edges of the slices are neat to ensure dimensional accuracy.

Features

- *Adjustable guide device for feed positioning;
- *Using electric rolling cutting strip
- *The meshing amount can be adjusted
- *Upper and lower blades with the same speed, synchronous transmission
- *Plexiglas protection device is arranged at the hob for safe operation
- *Open hob fixed mode, easy to disassemble the hob;* High cutting precision and reliable work;

Specifications

Model	Desktop Cylindrical Cell Electrode Slitting Machine MR-FT300
Cutter type	Up and down round knife
Cutter width	10~ 345mm
With knife spacing	56±0.1mm, 56±0.1mm, 56±0.1mm, 58±0.1mm, 58±0.1mm.58±0.1mm (can be customized)
Cutable thickness	50-400μm battery electrode
Up and Down gap	Handwheel adjusted 0.2-0.4mm
Cutter diameter	85mm
Cutter material	Ultra-fine grained alloy steel
Slitting speed	<2m/min,adjustable
Power supply	AC220V/50Hz (AC110V/60HZ)
Power Consumption	0.5KW
Dimensions	length 850 × width 620 × height 300 (mm)
Weight	60 KGS
Warranty	One year limited with lifetime technical support

Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.
- 5.All the parts use on machine, in stock forever.
6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer team have

more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.
7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbatteryachine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China