



10KVA Cylindrical Cell Machine Battery Bottom Spot Welder CE Approved

Our Product Introduction

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-DH650
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Name: Cylindrical Cell Bottom Spot Welder
- Max Output Power: 10KVA
- Welding Current: 0~99A
- Welding Range: 0.03~0.25mm Thickness Welding Strip
- Air Source: 0.3~0.7Mpa
- Power Supply: AC220V± 10%
- Highlight: 10KVA Cylindrical Cell Machine,
CE Cylindrical Cell Machine,
Cylindrical Cell Battery Bottom Spot Welder

for more products please visit us on lithiumbattery-machine.com

Product Description

Cylindrical Cell Bottom Spot Welder



Model: MR-DH650

Cylindrical Cell Bottom Spot Welder MR-DH650 is the most popular AC pulse Spot Welder driven by compressed air, which is controlled by microcomputer. It is designed for the production of the world's high-class battery manufacturer (NiMH, NiCd, Li-Ion/LiMnNi, LifePO4) with reliable performance. It is used for the welding of the negative electrode shell and the tab of the cylindrical battery (single-needle welding).

Features:

- *The welding current is stable, the solder joint size is uniform, the solder joint is beautiful, the spark is small, and there is no blackening.
- * Completely overcome the low pressure and water out of the lithium battery after spot welding, is the ideal equipment for the production of assembled batteries.
- * Single-pulse, double-pulse and multi-pulse welding can be realized by microcomputer single-chip control.
- * All parameters are digital settings, so the parameter adjustment is intuitive and accurate.
- *The welding pin pressure is independently adjusted, and the adjustment is convenient, ensuring stable and reliable welding pressure.
- * Alignment welding is accurate, suitable for welding of small cap batteries, and the yield is high.
- * The appearance is exquisite and beautiful, and light.

Specifications

Working Voltage	110 VAC, 50/60Hz or 220VAC, 50/60Hz
Output Power	10KW
Input Air Pressure	0.1 - 0.7 MPa (Air Compressor is not included)
Welding Current	0-99% Adjustable
Tab Thickness Applicable	0.03 - 0.25 mm tab Note: the spot welder is not suitable for welding foil (<20-micron thickness with tab. For the thin foil welding, please consider the ultrasonic welder.
Product Dimensions	L400×W560×H400mm
Warranty	One year limited warranty with lifetime support Rusting and damage due to improper storage condition or maintenance is not covered by warranty
Accessories	pedal type welding switch Air Compressor connect cable
Net Weight	45kg

Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.

5.All the parts use on machine, in stock forever.

6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer team have

more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.

7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbattery-machine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China