



Automatic Cylindrical Cell Machine 0.2KW Cyindrical Cell Sealing Machine AC220V 50Hz

Our Product Introduction

for more products please visit us on lithiumbatterymachine.com

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-ZDFK700
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Name: Automatic Cylindrical Cell Sealing Machine
- Sealing Die: 18650 Die Is Standard, Other Size Is Optional
- Crimping Accuracy: $\pm 0.1\text{mm}$
- Die Lifetime: 3 000 000 Times
- Capacity: 6 Pcs/min
- Compressed Air: 0.5~0.7MPa
- Highlight: Cylindrical Cell Machine 50Hz,
Cylindrical Cell Machine 0.2KW,
Automatic Cylindrical Cell Sealing Machine

Product Description

Cylindrical Cell Lab Equipment Automatic Cylindrical Cell Sealing Machine

Model: MR-ZDFK700

It is an automatic crimping machine designed for cylindrical cell case crimping, feeding & discharging automatically. After 3 times sealing processes, it carried out flat sealing edge, good air tightness, high dimensional accuracy, high efficiency, excellent consistency.

Key Features of Automatic Cylindrical Cell Sealing Machine

- PLC touch screen operation for technical parameters setting easily, with high automation.
- After 3 sealing processes, it carried out flat sealing edge, good air tightness, high dimensional accuracy, high efficiency, excellent consistency.
- High accuracy crimping die ensures excellent crimping and forming. It designed with quality steel structure, stable & safety for operation.
- Various of crimping die is optional for cylindrical cell making.
- Exquisite appearance, small volume, convenient for operation.

Technical Parameters of Automatic Cylindrical Cell Sealing Machine

Model	MR-ZDFK700
Voltage	AC220V, 50Hz
Power	0.2KW
Sealing die	18650 is standard, others die is optional
Sealing accuracy	±0.1mm
Die lifetime	>3 000 000 times
Capacity	6 pcs/ min
Compressed air	0.5~0.7MPa
Dimension	L550 * W400 * H1250mm
Weight	205kg

Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.
5. All the parts use on machine, in stock forever.
6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer team have more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.
7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbatteryemachine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China