



## 0.75KW Lithium Battery Manufacturing Machine 1400rpm Battery Mixing Equipment

### Our Product Introduction

for more products please visit us on [lithiumbatterymachine.com](http://lithiumbatterymachine.com)

#### Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-XJB-6
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



#### Product Specification

- Name: Mixing Equipment For Battery Manufacturing
- Power: AC110V/220V
- Mixing Speed: Max 1400rpm, 3 Segments Programable
- Mixing Container: 1-5L Optional
- Dimension: L330 \* W320 \* H570mm
- Weight: 35KGS
- Vacuum Degree: -98KPa (vacuum Pump Not Included)
- The Barrel Opening And Closing Mode: The Cylinder Drive Upper Cover Rises
- Highlight: **0.75KW Lithium Battery Manufacturing Machine , CE Lithium Battery Manufacturing Machine, 1400rpm Battery Mixing Equipment**

## Battery Making Machine Mixing Equipment for Battery Manufacturing



**Model:**MR-JB-6

### Product Introduction

MR-JB-6 is a high-efficiency equipment integrating vacuum mixing and dispersing. It is suitable for the positive and negative electrode slurry mixing in the battery experiment process, as well as the mixing of powder materials and various ceramics. By programming the controller to set the time, speed, and the direction of rotate.

### Features

- \*Using the industry-leading soft sealing process, it can maintain -0.098Mpa for more than 24 hours;
- \*Adopting precision guide column support, the cylinder automatically pushes the barrel to open and close, humanized design, precise and efficient;
- \*1L double-layer stainless steel container, the barrel body is made of high quality 304 stainless steel, and the lathe is finished and then polished by precision automatic polishing machine to ensure high precision;
- \*The Speed range is 0 to 1400 rpm, time, speed, and the direction of rotation can be set by the controller.
- \*The motor adopts the gearbox frequency conversion adjustment, which can select different speed and torque according to different material and viscosities;
- \*Doubly dispersed blade design, the material is tumbling up and down and around, so that the slurry is mixed quickly and evenly;
- \* Small size, saving space;
- \* Exquisite appearance, using three-dimensional geometric design, simple and beautiful;

### Specifications

Rated power	0.75KW, 220V
Stirring speed	0-1400 RPM / min; speed can be adjusted by frequency converter;
Vacuum degree	-98KPa (vacuum pump not included)

Mixing Container	1L
The Barrel Opening and Closing Mode	the cylinder drive upper cover rises
Machine size	700 H * 600 L* 300 W mm
Timing function	you can set the time 0-99 (H)
Weight	90kg
Compliance	CE Certified
Warranty	One year limited with lifetime technical support

#### Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.
- 5.All the parts use on machine, in stock forever.
6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer team have more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.
7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .



**Shenzhen Meirui Zhida Technology Co., Ltd.**



+86 19866156608



tina@szmrbest.com



lithiumbatteryemachine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China