



Max 6m/min Heat Calendering Machine For Battery Electrode Rolling

Our Product Introduction

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-DG300C
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Product Name: Heat Calendering Machine For Battery Electrode Rolling
- Roller Diameter: $\phi 200\text{mm}$
- Roller Width: 330mm
- Pressing Speed: Max 6m/min
- Installation Size: L2500 X W1500 X H1300mm
- Weight: 600kg
- Winding And Unwinding System: Included
- Heating Function: Optional
- Highlight: **6m/min Heat Calendering Machine, Battery Heat Calendering Machine, Battery Electrode Calendering Machine**

Product Description

Battery Making Machine Heat Calendering Machine For Battery Electrode Rolling



Model: MR-DG300C

MR-DG300C is a hot hydraulic rolling press machine with winding & unwinding system, which is used for battery electrode rolling press process.

Main Features:

- The pressing thickness is adjustable.
- It is designed with tension control.
- Winding&unwinding device with correction function.
- Touch screen control, high automation.
- RT~130 heating temperature adjustable.

Specifications:

Model	Heat Calendering Machine For Battery Electrode RollingMR-DG300C
Power	AC220V
Heating temperature	RT~130 adjustable
Pressing speed	Max 6m/min
Roller diameter	φ330mm
Roller material	9Cr3Mo
Roller surface hardness	HRC65
Roller width	330mm
Pressing thickness	Max 2mm
Pressing accuracy	±1.5μm
Power	3KW
Installation size	L2500 x W1500 x H1300mm (Roll press machine + winding & unwinding device)
Compressed air	0.5~0.8Mpa
Weight	≈ 600kg

Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.
- 5.All the parts use on machine, in stock forever.
6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer team have more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.

7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbattery-machine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China