



2KW Lithium Battery Making Machine Pouch Cell Hot / Cold Press Machine

Our Product Introduction

for more products please visit us on lithiumbattery-machine.com

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-RY200
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Product Name: Pouch Cell Hot/Cold Press Machine
- Hot Press Area: 200*200mm
- Heating TEM: RT-250 , Adjustable
- TEM accuracy : ± 2
- Pressure: 1T Adjustable
- Air source: 0.5-0.8MPa
- Power: 2KW
- Voltage: AC110V / 220V Optional
- Highlight: **2KW Lithium Battery Making Machine,
Cold Press Lithium Battery Making Machine**

Product Description

Pouch Cell Hot/Cold Press Machine For Lithium Battery Core Formation



Model: MR-RY200

MR-RY200 Pouch Cell Hot/Cold Press Machine is used for pouch cell cores hot flat pressing after stacking & winding to makes it easy to put into aluminium-laminated case and pouch cell formation. The heating pressing die size is L200 x W200mm. The upper and lower pressing plate temperature can be controlled independently and digital display by thermometer.

Features

- Upper and lower pressing die temperature can be controlled independently.
- Heating temperature adjustable from room temperature ~250 and digital display.
- Pressing pressure can be adjusted.
- Heating press time can be set.
- The heating pressing die is made from copper with good heat conduction.
- IR sensor and protection cover included for safety protection.

Technical Parameters

Model	Pouch Cell Hot/Cold Press Machine MR-RY200
Working voltage	AC110V / 220V optional
Pressing die size	L200 * W200mm
Heating temperature	Room temperature ~250 adjustable
Temperature accuracy	± 2
Heating power	1KW
Pressure	Max 1T
Compressed air	0.5~0.7Mpa
Dimension	L320 * W320 * H430mm
Weight	70kg

Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.
5. All the parts use on machine, in stock forever.
6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer team have more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.
7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .





+86 19866156608



tina@szmrbest.com



lithiumbattery-machine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China