



Semi Auto Pouch Cell Forming Machine 100W 0.5 - 0.7MPa Air Source

Our Product Introduction

for more products please visit us on lithiumbatterymachine.com

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-SCK300
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Product Name: Pouch Cell Forming Machine
- Application: For Battery Research
- Suitable Battery: Pouch Cell
- Suitable Aluminum Film Thickness: 0.1-0.2mm
- Punch Cup Dimension: Max L250 * W150mm, Customizable
- Punching Depth: ≤ 6mm Adjustable, Can Be Customized
- Power: 100W
- Output Pressure : 3T
- Highlight: **Pouch Cell Forming Machine 100W, Semi Auto Pouch Cell Forming Machine**

Product Description

Battery Making Machine Pouch Cell Forming Machine



Model: MR-SCK300

MR-SCK300 Semi-auto Case/ Cup Forming Machine is used for preparation. It is a semi-auto pouch cell aluminum laminated films cup forming machine, the punching thickness is adjustable. The pouched case without crow's feet and corner collapse. IR sensor, dual start buttons and protection cover are included for safety operation.

Features

- * Adopting four guide pillar structure, sliding up and down smoothly and high precision;
- * It is simple and quick to change the mold and adjust the depth.
- * Compared with similar products, the aluminum laminated film of the same quality stretches deeper and more stable.
- * Precise mold design, no crow's feet and corners at all corners and surroundings after forming;
- * Use light curtain and outer cover to protect, safe to use;
- * Using Japanese imported mold material and high-strength chrome steel and alloy aluminum, the surface is treated with environmentally friendly electroplating and baking paint;
- * Exquisite appearance, the sheet metal adopts three-dimensional geometric design, which is simple and beautiful;
- * Easy to operate, safe and reliable, small size;

Specifications

Model	Pouch Cell Forming Machine MR-SCK300
Source voltage	AC 220V/110V, 50/60HZ
Power	100W
Warranty	One year limited warranty with lifetime support
Advantages	1. Structure of guide pin, slide up and down smoothly with high precision 2. Change mould, adjust tensile depth simply, quickly 3. Use screen and casing protection, guarantee safety 4. High strength of chrome steel and aluminum alloy, surface roasts the paint processing through environmental protection electroplating
Suitable aluminum film thickness	0.1-0.2mm
Suitable mold size	300*280mm(L*W), customized, with punching depth ≤6mm
Max. Cup Depth	Single pit punching depth ≤6mm
Output	200-400EA/H
Output pressure	3T
Air source	0.5-0.7MPa
Mold materials	SS136 Die steel
Dimension (L*W*H)	460*320*925mm
Weight	About 150kg

Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.
- 5.All the parts use on machine, in stock forever.
6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer team have more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.
7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbattery-machine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China