



20W Lithium Battery Making Machine Pneumatic Battery Edge Folding Machine

Our Product Introduction

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-ZP200
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Name: Pneumatic Battery Edge Folding Machine
- Folding Width: 2-11mm
- Max. Folding Length: 200mm
- Compress Air Pressure Requirement: 0.5 - 0.7 MPa (Each Stroke Will Consume 0.09L Air)
- Stroke Frequency: 9 Seconds Per Trial
- Max. Power Consumption: 20W
- Highlight: **20W Lithium Battery Making Machine, Pneumatic Lithium Battery Making Machine, Pneumatic Battery Edge Folding Machine**

Product Description

200mm Pneumatic Battery Edge Folding Machine



Model: MR-ZP200

MR-ZP200 is widely used in the final steps of pouch cell battery pilot-scale production line to ensure a smooth, neat and tidy casing edge.

Features

- 1 Folding width can be adjusted for different battery.
- 2 Air pressure, speed can be adjusted.
- 3 Adopted foot switch, Reliable, convenient and quick
- 4 Small size, simple operation

Specifications

Model	Battery Edge Folding Machine MR-ZP200
Max. Power Consumption	20W
Working Voltage	110 - 240VAC, single phase
Compress Air Pressure Requirement	0.5 - 0.7 MPa (Each stroke will consume 0.09L air)
Size Info (Folding Length)	Folding Width: 2-11mm Max. Folding Length:200mm
Stroke Frequency	~9 seconds per trial
How to use this Tool Suite	When the pouch cell is fabricated, an uneven edging excess is expected. In order to make a neat and tidy cell with smooth edge just like the commercial pouch batteries, please follow the steps in below: Step 1. Use the MR-QP200 trimming machine to cut off the excess area of the casing edge, only leave the size appropriate for the edge folding and ironing Step 2. Use the MR-TP200 ironing machine to smooth the edge prior to the folding Step 3. Use the MR-ZP200 folding machine to partially fold the edge Step 4. Use the MR-TP200 ironing machine to smooth the folded section again and then iron the longer section against the sides of the case. Now a neat and tidy cell is finished.
Net Weight	31kg
Product Dimensions	L320*W300*H420mm
Compliance	CE Certificate
Warranty	One Year limited warranty with lifetime support

Standard Package List

Item	Qty
Battery edge folding machine	1 set
Power line (according to your requirements)	1 pcs
Foot pedal	1 pcs

socket head wrench	1 set
Operating manual (English)	1 book

Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.
- 5.All the parts use on machine, in stock forever.
6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer team have more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.
7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbatteryachine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China