



Z Fashion Battery Stacking Machine 100W for Lithium Ion Battery Assembly Line

Our Product Introduction

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-BDP200-A
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Product Name: China Battery Stacking Machine Manufacturers
- Stacking mode: Z Fashion
- Max separator feeding diameter: 25mm
- Fixed Travel Distance: 300mm
- Applicable electrode Size: Length: 20 200mm Width: 20 200mm Thickness: Within 18mm
- Travel Cycle: 1 - 9999 Cycles
- Power: 100W
- Working Voltage: AC110V-220V 50/60Hz
- Highlight: **Z Fashion Battery Stacking Machine, Battery Stacking Machine 100W**

China Battery Stacking Machine Manufacturer for Lithium Ion Battery Assembly Line



Model: MR-BDP200-A

MR-BDP200-A is a desktop semi-auto stacking machine, which is used for stacking pouch cell anode, cathode and separator by "Z" shape to make a pouch battery core. The stacking size is adjustable from L20~200mm to W20~200mm.

Main Features:

- Stacking size is adjustable.
- Counter is designed.
- Desktop design, compact size.
- Control part and working part split design, easy to operate.

Technical Specifications

Model	China Battery Stacking Machine Manufacturer MR-BDP200-A
Working voltage	AC110/220V optional
Stacking size	L(20~200)mm x W(20~200)mm
Separator roll diameter	Max ϕ 250mm
Traveling stroke	300mm
Air source	0.5~0.7Mpa
Operation mode	Semi-auto
Dimension	Control part: L650 * W400 * H700mm Working part: L200 * W200 * H380mm
Weight	60kg

Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.
- 5.All the parts use on machine, in stock forever.
6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer

team have

more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.

7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbatteryachine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China