



Semi Auto Pouch Cell Die Cutting Machine 3T Air Cylinder 0.5 - 0.7Mpa Air Pressure

Our Product Introduction

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-MQ280
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Product Name: Pouch Cell Die Cutting Machine
- Maximum Die Cutting Size: 280x180mm
- Punching Accuracy: ± 0.1 Mm
- Vertical Burr: $\leq 15\mu\text{m}$
- Horizontal Burr: $\leq 20\mu\text{m}$
- The Life Of The Die: Normal Use $\geq 30,000$ Times
- Air Cylinder: 3 Tons Max. Pressure
- Die Cutting Stroke: 150mm
- Highlight: **Semi Auto Pouch Cell Die Cutting Machine, Pouch Cell Die Cutting Machine 3T**

Product Description

Battery Research Equipment Pouch Cell Die Cutting Machine For Pouch Cell Electrode Cutting



Model: MR-MQ280

MR-MQ280 semi-auto electrode die cutter is a necessary equipment for pouch cell preparation. It is used for pouch cell electrode cutting to produce specific shapes of cathode and anode with current collector tab. Dual start buttons to ensure safety operation to avoid hands injured. The cutting without burr and high accuracy.

Features

- Different size of cutting die can be optional and easy to replace.
- The cutting no burr, no coated material drop.
- 2 Start buttons, the die can only go down only when pressing the 2 buttons at the time to avoid hurting hands.
- It is designed with counter, the operator can know the cutting numbers easily.
- It is semi-auto, high cutting speed.
- Long lifetime for the cutting die, >30000 times.

Instructions

Put the electrode into the die-cutting position, and then press the foot switch. The booster cylinder drives the die-cutting knife group to automatically cut the electrode.

Specifications:

| | |
|------------------|---|
| Model | Pouch Cell Die Cutting Machine MR-MQ280 |
| Working Voltage | AC110/220V optional |
| Cutting Die Size | maximum L280 * W180mm, customized size is available |
| Cuting Accuracy | ±0.1mm |
| Air Cylinder | 3T |
| Air Pressure | 0.5~0.7Mpa |
| Material Feeding | Manual |
| Capacity | 800~2000pcs/h |
| Dimension | L550 * W455 * H900mm |
| Weight | 170kg |



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbatterymachine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China

