



MR-LFT300 Supercapacitor Equipment Roll To Roll Continuous Electrode Slitting Machine

Our Product Introduction

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Certification: CE
- Model Number: MR-LFT300
- Minimum Order Quantity: 1 Set
- Price: Negotiable
- Packaging Details: Standard Export Wooden Packing
- Delivery Time: 7-20 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 500 sets per month



Product Specification

- Name: Roll To Roll Continuous Electrode Slitting Machine
- Slitting Width: Range 20~230mm / 20~280mm Can Be Customized
- Cutting Thickness: 100~300μm
- Slitting Blade Diameter: φ100mm
- Slitting Accuracy: ±0.09mm
- Burrs: ≤25μm
- Highlight: Continuous Supercapacitor Equipment, Supercapacitor Roll To Roll Slitting Machine, Continuous Electrode Slitting Machine

Product Description

Supercapacitor Equipment Roll to Roll Continuous Electrode Slitting Machine



Model: MR-LFT300

It is used for roll-type material multiple strips continuous slitting. High accuracy slitting blade, which can carry out extremely high precision foil cutting. It is also widely applied in li-ion battery, metal foils, optical film and other functional film industries.

Main Features

- Ultra-fine tungsten alloy slitting blade, great performance in slitting electrode, longer lifetime.
- High accuracy of slitting width, no burrs, wave and indentation.
- The engagement is adjustable, the ratio of blade speed to material linear speed is adjustable.
- It is capable to carry out slitting for various of material & thickness by adjusting the angle of charging & discharging.
- The winding tension is automatically controlled, the upper and lower shaft are independently adjustable within 50N.
- PLC control & HMI operation, easy for using.

Technical Parameters

Model	Roll To Roll Continuous Electrode Slitting Machine MR-LFT300
Slitting method :	Monolithic roll cutting
Cutter type :	Upper and lower circular knife
Width adjustment:	Replace spacer adjustment, will suggest Complete set design, easy to disassemble
Materials thickness:	100 ~ 300μm
Slitting blade:	Ultra fine alloy steel, diameter Φ100mm
Slitting width:	Adjustment range 20 ~ 280mm(can be customized)
Burr condition:	≤25μm
Slitting accuracy	±0.09mm
The amount for the feed knife	0.2 ~ 0.4mm adjustable, dial indicator display
Slitting speed:	Max. 4m / min
Power supply:	Single-phase voltage 220VAC ± 10%, frequency 50Hz / 60Hz, power 1kW
Work environment:	Recommended ambient temperature 25 ± 3 , humidity 30 ~ 90RH, no vibration and electromagnetic interference
Installation size:	L850mm*W800mm*H650mm
Weight:	365Kg
Package Size:	1100*1040*1340mm
Gross Weight:	450KG

Our Advantages

1. Steady and high quality ! -cause we are a manufacturer of Lithium Battery Equipment, and we only focus on one thing that is make professional Lithium ion Battery Equipment for customer around the world.
2. Friendly use! all MRBEST Battery Equipment with teach manual and support live teaching via media.
3. Reliable factory! My factory located in Shenzhen city of China, support factory visit and video factory visit .
4. 1 year warranty plus lifetime technical support.
- 5.All the parts use on machine, in stock forever.
6. Powerful technical support, NOT TRADE COMPANY! We are professional on Lithium Battery Equipment, the chief engineer

team have

more than 20 years experience on lithium battery area, so we can easy do diagnose on machine if customer have question.

7. 100% PATIENCE to all customers! Our patience not only before consult order, also after-sale service, one by one .



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbatteryachine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China