



SS304 SS316 Battery Materials CR2032 Button Cell Battery Case

Our Product Introduction

for more products please visit us on lithiumbatterymachine.com

Basic Information

- Place of Origin: China
- Brand Name: MRBEST
- Model Number: CR2032
- Minimum Order Quantity: 100 Sets
- Price: Negotiable
- Packaging Details: Standard Export Carton Packing
- Delivery Time: 3-15 working days
- Payment Terms: T/T, Western Union, MoneyGram
- Supply Ability: 5000000 sets per month



Product Specification

- Name: SS316 CR2032 Button Cell Cases
- Shape: Button
- Material: SS316
- Battery Size: 20 Mm *3.2 Mm
- Sealing Gasket: PP
- Full Set Include: Positive Case, Negative Case, Spring And Spacer
- Highlight: **SS316 Battery Materials,
SS304 Battery Materials,
CR2032 Button Cell Battery Case**

Product Description

SS316 CR2032 Button Cell Cases for Coin Cell Battery Research



CR2032/ CR2025/ CR2016 button cells cases, made of stainless steel 316 with PP sealing O-ring

1 set include positive case, negative case, conical spring and spacer.

Dimensions (Dia x Height)	20 mm x 3.2 mm
Weight	1KG
Material	Casing: SS304 or SS316, please choose according to your need. Sealing Gasket: PP The thickness of the SS304/316 for both anode and cathode case is 0.25 mm +/- 0.02 mm.
Application Note	After perfectly crimping, the External Height should be around 3.0mm. The diameter of the inner ring of the plastic gasket for the coin cell 2032 is around 16.39mm. Usually, a case does not need to clean before crimping, but if you do need to clean the case, please put in ethanol for 4-6 hrs, and use Oven to dry several hours, (please set the oven to 30C, if it has ORING.)
Model Choose	CR2032/ CR2025/ CR2016

Application:

It is excellent for developing new rechargeable batteries and battery electrodes



Shenzhen Meirui Zhida Technology Co., Ltd.



+86 19866156608



tina@szmrbest.com



lithiumbatterymachine.com

104 Building 6, Second Industrial Zone, Shanmen Community, Yanluo Street, Baoan District, Shenzhen China

